



ATTN: OHV SECTION

555 Wright Way

Carson City, NV 89711

(775) 684-4381

www.ohv.nv.gov

OFF-HIGHWAY VEHICLE IDENTIFICATION NUMBER TAG INSTALLATION INSTRUCTIONS

Your new vehicle identification number (VIN) tag is enclosed. You must install the tag or have the tag installed in accordance with the directions below. **If you are not comfortable installing the VIN tag, seek the help of a reputable shop.**

1. Locate the proper area to place the VIN tag.
 - A. If known, permanently attach the VIN tag to the location used by the original manufacturer.
 - B. If the off-highway vehicle (OHV) is a closed body vehicle and the location used by the original manufacturer is not known or the vehicle is homemade, permanently attach the VIN tag to:
 - (1) The pillar post for the left door hinge or;
 - (2) If such placement is not appropriate, the left side of the firewall or under the hood.
 - C. If the OHV is a tube-frame type vehicle and the location used by the original manufacturer is not known or the OHV is homemade, permanently attach the VIN tag to a protected area of the tubing.
 - D. For motorcycles permanently attach the VIN tag to the frame on or as near as possible to the right side down tube.
2. Install the VIN tag.
 - A. The VIN tag should be attached when the temperature is between 50 degrees Fahrenheit and 100 degrees Fahrenheit so the adhesive on the back of the tag will properly adhere.
 - B. Thoroughly clean and dry the surface that the VIN tag will be attached to. Be sure to remove wax, tar, dirt and other foreign matter. Use the rivets supplied by the DMV inspector to permanently attach the tag.

For more information, please visit the website of the Nevada Commission on Off-Highway Vehicles at www.ohv.nv.gov or call (775) 684-4381